



Einhell

EXPERT Plus

POWER X CHANGE

GE-LC 18 Li - Solo

Cordless Chain Saw

Item No.: 4501761

Ident No.: 11015

Bar Code: 4006825608342

The Einhell cordless GE-LC 18 Li Solo combines the outstanding quality of an Einhell product with the cutting performance of a high-quality OREGON guide bar and chain. Kickback protection and an instant-reaction mechanical chain brake protect you while you are working with the chainsaw. A catch bolt holds on to the chain if it jumps off the rail. The rugged metal stop claw keeps the saw stable for your added safety. The ergonomic handle gives you a firm grip on the cordless chainsaw. No tools are needed to adjust the chain tension or replace the chain. The chain is lubricated automatically. The large opening in the oil reservoir eliminates the need for a funnel. This product comes without a battery or charger.

Features

- High-quality chain and bar from OREGON
- Toolless chain tensioning and changing
- Ergonomic handle
- Sturdy stop claws made of metal
- Kickback protection with mechanical instant chain brake
- Big filler opening
- Automatic chain lubrication
- Chain catch bolt
- No battery and no charger



Technical Data

- Sword length 250 mm
- Max. cutting length 230 mm
- Chain cutting speed 4.3 m/s
- Oil tank capacity 200 mL

Logistic Data

- Product weight (kg) 2.9 kg
- Gross weight (kg) 3.99 kg
- Dimensions single packaging 255 x 435 x 225 mm
- Pieces per export carton 2 Pieces
- Gross weight export carton 10.6 kg
- Dimensions Export Carton 450 x 465 x 275 mm
- Container quantity (20"/40"/40"HC) 960 | 1952 | 2196



TOOLLESS CHAIN TENSIONING



ERGONOMIC HANDLE



SOFTGRIP



FITTED WITH
OREGON
CHAIN AND BAR



Available as special accessories



Ersatzkette 25cm 1,1 40T 3/8
Chain Saw Accessory
Item No.: 4501754
Bar Code: 4006825607024
Einhell Grey



Ersatzschwert 25cm 1,1
Chain Saw Accessory
Item No.: 4501753
Bar Code: 4006825607017
Einhell Grey



18V 5,2 Ah Power-X-Change
Battery
Item No.: 4511357
Bar Code: 4006825598865
Einhell Accessory



18V 3,0 Ah Power-X-Change
Battery
Item No.: 4511341
Bar Code: 4006825590593
Einhell Accessory



18V 2,0 Ah Power-X-Change
Battery
Item No.: 4511395
Bar Code: 4006825610369
Einhell Accessory



18V 4,0 Ah Power-X-Change
Battery
Item No.: 4511396
Bar Code: 4006825610376
Einhell Accessory



18V 30min Power-X-Change
PXC-Charger
Item No.: 4512011
Bar Code: 4006825587029
Einhell Accessory