

MANUALE ISTRUZIONI  
INSTRUCTION MANUAL  
MODE D'EMPLOI  
BEDIENUNGSSANLEITUNGEN

BEDIENINGSHANDLEIDING  
MANUAL DE INSTRUCCIONES  
MANUAL DE INSTRUÇÕES  
INSTRUKCJA OBSŁUGI

DECESPUGLIATORI  
BRUSH CUTTERS  
DEBROUSSAILLEUSES  
FREISCHNEIDER  
STRIKENSNOEIERS  
DESBROZADORAS  
ROÇADORAS  
KOSIARKA



- (I) Leggere attentamente le presenti istruzioni prima del primo impiego.
- (GB) Read this operators manual carefully before the first use.
- (F) Lire avec attention ces instructions avant la première utilisation.
- (D) Vor der Anwendung die vorliegenden Anweisungen aufmerksam lesen.
- (NL) Lees aandachtig deze instructies door alvorens het apparaat voor het eerst in gebruik te nemen.
- (E) Leer con cuidado estas instrucciones antes de la primera utilización.
- (P) Leia com atenção estas instruções antes de utilizar pela primeira vez o aparelho.
- (PL) Przed pierwszym użyciem należy uważnie przeczytać niniejszą instrukcję.

CE

## 9. SPECIFICATION

Specifications	Items	Brush Cutters				
		BC260	BC330	BC415B	BC520	BC415-6
Handle Type		Loop	Loop	Loop	Both Hands	Both Hands
Power Transmission Method		Automatic centrifugal clutch, spiral gear				
Applied Blade		4-teeth blade, 8-teeth blade, bamboo blade, round saw blade, nylon cutter				
Blade Rotation Direction		Counter clockwise(from operator's view)				
Outward Size(L*W*H)cm		182*26*22	183*61*42			
Weight(kg)		5.3	7.0	7.4	7.4	7.4
Engine	Manufacturer	China or Japan				
	Type	Single cylinder, air-cooling 2-cycle gasoline engine				
	Displacement volume(cc)	25.4	32.5	42.7	52	40.2
	Carburetor	Diaphragm, Rotary valve		Diaphragm, Rotary valve		Float
	Start Method	Recoil starter				
	Stopping Method	Sparking Circuit Primary short				
	Fuel Used	Lubricating oil mixed gasoline(mixing rate 25:1)				
	Lubricating oil Used	2-cycle engine oil				
	Fuel Tank Capacity(L)	0.6	0.8	1.0	1.0	1.0